


Instruction Manual

Thank you for choosing Richell's Wire Top 90-60.
Please read this instruction manual carefully before assembling or using this product,
and keep for future reference.

Futures

This product is designed exclusively for Richell's Wood Pet Pen 90-60.
Removable Wire Top.

Parts / Specifications



Dimension: 35" W x 23.6D x 2H
(89cmW x 60D x 5H)

Materials: Wire Panel: Steel
Lock: ABS resin

Cautions


- Do not use this product for anything other than its intended purpose.
- Keep the product away from fire or extremely high temperatures.
- Do not stand or sit on the product, as it may cause injury/damage to person or product.
- Do not grasp Top Panel when moving the product.
- Do not place anything on Top Panel.
- Use mild detergent to clean. Do not use harsh chemicals such as benzine or thinner.

How to attach Top Panel to Pen

Note:


This product is designed exclusively for Richell's Wood Pet Pen 90-60.
Wood Pet Pen 90-60 and Tray 90-60 are sold separately.

- (1) Place the rear hooks of Top Panel on Top Frame as shown.
- (2) Lower the front of Top Panel to Top Frame and lock as shown.



A. How to open Top Panel

Slide Locks of Top Panel to the back as shown.



If you find something wrong with this product, please let us know, thank you!

Designed by:
Richell Corporation, Japan

Distributed by:
Richell USA Inc.
2100 N. Hwy. 360, Suite 1700, Grand Prairie, TX 75050
Phone (972) 641-9795 Fax (972) 641-8495
Visit us at www.richellusa.com
Made in China